

ICN2037

(16-Channel Constant Current LED Sink Driver with Dual Latch)



Description

The ICN2037 is a 16-channel constant current sink output LED driver. All 16-channels constant current can be set by a single external resistor, which provides users flexibility in controlling the light intensity of LEDs.

The ICN2037 exploits current precision controlling technology , which makes error between ICs less than $\pm 2.5\%$, and error between channels less than $\pm 3.0\%$. At ICN2037 output stage , 16-regulated output ports are designed to provide uniform and constant current sinks for driving LEDs within a large range of forward voltage(VF) variations.

ICN2037 contains two 16-bit shift registers and latches which convert serial input data into parallel output format. For integrated dual latch, ICN2037 could get higher refresh rate.

Features 16-channel constant current output

- ♦ Output current setting range : 3~45mA×16@V_{DD}=5V constant current output 3~30mA×16@V_{DD}=3.3Vconstant current output
- ♦ Current accuracy
 Between channel :< ±3.0%
 Between ICs :< ± 2.5%
- → Fast response of output current, → OE (min):40ns@V_{DD}=5V
- ♦ ESD HBM PASS 8KV
- ♦ I/O: Schmitt trigger input
- ♦ Data transfer frequency:f_{MAX}=30MHz(Max)
- ♦ Power supply voltage: VDD=3.3 ~ 5V
- ♦ Operating Temperature: –40°C to +85°C
- Pre-Charge for Ghosting Reduction
- ♦ LED Protection
- ♦ Enhanced Circuit for Caterpillar Cancelling
- ♦ Low-Gray Scale Enhancement
- Integrated Dual Latch for higher refresh rate

Package

Shrink SOP

AP/BP: SSOP24-P-150-0.635

ICN2037

www.chiponeic.com V2.0 Nov 2017